

FT300 & FT310

Backboard Height Adjusters

Bill of Materials

- (1) Height adjuster
- (1) Adjustment Handle
- (8) 3/8"x 2" Hex Bolt
- (2) 3/8"x 3 1/4" Hex Bolt
- (20) 3/8" Flatwasher
- (8) 3/8" Lockwasher
- (8) 3/8" Hex Nut
- (2) 3/8" Centerlock Nut (centerlock nuts have small square indentation on side of nut)

INSTALLATION TIPS

When installing your backboard height adjuster, keep in mind that the side with the height sticker is the **BACK SIDE** of the adjuster. Install the adjuster with the sticker facing **AWAY** from the basketball court.

IF YOUR BOTTOM TWO RIM BOLTS ARE TOO LONG: In this bolt kit you will find extra rim mounting hardware, (2) 3/8"x 3 1/4" hex bolts, (2) 3/8" flatwasher and (2) 3/8" centerlock nut. This hardware will be useful if you find the rim mounting bolts packaged with your rim are too long for the bottom two rim attachment points. Use only the centerlock nut on the backside of backboard for tightening bolt (no washer on backside of backboard)

IF YOU PURCHASED FT310 HEIGHT ADJUSTER WITH BACKBOARD PAD: It will be necessary to cut the 1" lip off the back side of the backboard pad using a box cutter knife.

Adjustment Screw – Make sure to grease the adjustment screw before first use. If adjustment is rough, also check to make sure the adjustment screw is running perpendicular to the floor (straight up and down). If not, there is a leveling plate that can be used at the bottom of the height adjuster to allow repositioning of the screw.